

Support model
RTL 8187B
RTL 8187L
RTL 8187SE
RTL 8187SU
RTL 8710 / 8711
RTL 8185B
RTL 8185
RTL 8186
RTL 8190
RTL 8192E
RTL 8192U
RTL 8188SU / 8191SU
RTL 8192SU
RTL 8191SE
RTL 8192SE
RTL 8196B + 8191RE
RTL 8196B + 8192SE
RTL 8709
RTL 8712
RTL 8672
RTL 8196C + 8188CE
RTL 8196C + 8192CE
RTL 8198 + 8188CE
RTL 8198 + 8192CE
RTL8188CE
RTL 8188CE + CSR BC04
RTL 8188CE + CSR BC08
RTL 8192CE
RTL 8188CU
RTL 8188CUS
RTL 8192CU
RTL 8192DE
RTL 8196C + 92DE
RTL 8672vK
RTL8188(92)CE
RTL8723AE
RTL8723AE_BT
RTL8192DU
RTL819xCU
RTL819x AP